



OPERATING INSTRUCTIONS



Unpack box



Place one stand on table & line up velcro



Push firmly to secure Leg to T-Rex body™



Repeat with other Leg.



Inflate your 5 inch balloons with your air source



Turning T Rex™ on it's front size balloons in back of T-Rex™ to get correct size



Deflate balloon until it is the balloon is just smaller than the tube of the T-Rex™



Turn T-Rex right side up & assure the legs are firmly affixed to the body.



For extra strength - use elastic bands to secure body of T-Rex™ to Legs



Loop Elastic Bands over the T-Rex™ into hooks on legs



Assure T-Rex™ is secure & balanced.




Affix Hose to underneath of T-Rex™- no clamps are required.



Attach other end of hose to your air inflator , again , no clamps are required.



Place T-Rex™ in position if you are right handed put back of T-Rex™ to your right



Clamp T-Rex™ to the table securing at least 3 feet. (clamps not included)




Assure clamps are in place and secure before starting.



Assure clamps are in place and secure before starting.



Roll hands down the neck of your large balloon to get to the main body & stretch



Open neck of balloon and stretch over the front opening of the T-Rex™- stretch it wide and from the top down to the bottom stretch it over the opening (this is the tricky part, with a little practice you will succeed)



OPERATING INSTRUCTIONS *continued*



Balloon is now stretched and ready for airflow to be turned on.



Turn on air inflator.



Keep supply of 5" balloons in a handy location so they can be easily fed through.




Take first 5" balloon and place in the back end of the T-Rex™



Hold 5" balloon in place and larger balloon will start to inflate.



When larger balloon is partially inflated, push 5" balloon all the way through keeping your hand inside bigger balloon till air escapes



Repeat process with next balloon and so on and so on



You can increase speed of stuffing by having one 5" balloon pushing another thru



You can inflate up to 20 5" balloons before you need to deflate the bigger balloon



IMPORTANT TRICK - keep your hand inside the larger balloon when you need to let the air out of the Bigger balloon - this will PREVENT the smaller balloons from escaping with the air.....the air will pass over the top of your arm in the T-Rex™



When you have finished stuffing your Bigger Balloon, turn off your air inflator and simply roll the neck of the Bigger balloon off the end of the T-Rex™



CONGRATULATIONS - you now have a STUFFED balloon ready to helium fill or air fill to created EYE CATCHING decor or stunning exploding balloons.

FOR EXPLODING BALLOONS USE



No Wires No Fuss



INNOVATIVE BALLOON TECHNOLOGIES

Enquiries / Sales www.balloontec.com email: sales@balloontec.com